IN THE UNITED STATES DISTRICT COURT FOR THE DISTRICT OF DELAWARE

SIEMENS MEDICAL SOLUTIONS USA,)	
INC.,)	
)	
Plaintiff,)	
)	C.A. No. 07-190 (SLR)
v.)	
)	REDACTED VERSION
SAINT-GOBAIN CERAMICS &)	
PLASTICS, INC.,)	
)	
Defendant.)	

AFFIDAVIT OF NIRAJ DOSHI

MORRIS, NICHOLS, ARSHT & TUNNELL LLP Jack B. Blumenfeld (I.D. No. 1014) Maryellen Noreika (I.D. No. 3208) 1201 North Market Street P.O. Box 1347 Wilmington, DE 19899 (302) 658-9200 jblumenfeld@mnat.com

Attorneys for Plaintiff
Siemens Medical Solutions USA, Inc.

Of Counsel:

Gregg F. LoCascio Charanjit Brahma Sean M. McEldowney KIRKLAND & ELLIS LLP 655 15th Street, N.W., Suite 1200 Washington, D.C. 20005-5793 (202) 879-5000

Original Filing: July 9, 2007 Redacted Filing: July 16, 2007

IN THE UNITED STATES DISTRICT COURT FOR THE DISTRICT OF DELAWARE

SIEMENS MEDICAL SOLUTIONS USA, INC.,)	
Plaintiff,)	Civil Action No. 07-190 SLR
v.)	CIVILIONO I 10. 07 170 BERC
SAINT-GOBAIN CERAMICS &)	
PLASTICS, INC.,)	
Defendant.)	

AFFIDAVIT OF NIRAJ DOSHI

I, Niraj Doshi, hereby declare:

- 1. I am presently employed by Siemens Medical Solutions, Inc. ("Siemens") and have been employed by Siemens or its predecessor, CTI, Inc. since July 2000.
- 2. I have a Ph.D. in Biomedical Physics from the University of California, Los Angeles (UCLA).
- 3. On or about December 6, 2006, Siemens requested from the University of Tennessee samples of lutetium-yttrium orthosilicate ("LYSO") crystals manufactured by Saint-Gobain Ceramics & Plastics, Inc. ("Saint-Gobain") or its corporate affiliates. On or about February 14, 2007, Siemens received samples that had been sold to the University of Tennessee by Saint-Gobain along with what is, to the best of my knowledge, the March 24, 2004, invoice (Exhibit A) under which these sample LYSO crystals were sold to the University by Saint-

Gobain. To the best of my knowledge, the quotation from Saint-Gobain to the University for this sale is attached as Exhibit B. The quotation indicates that the sample LYSO crystals from Saint-Gobain were produced in France.

- 4. I and others under my supervision at Siemens tested these sample LYSO crystals to determine how similar their scintillation properties were to those of Siemens' patented lutetium oxyorthosilicate ("LSO") crystals. Particularly, Saint-Gobain's LYSO crystals were tested and compared to Siemens' LSO crystals for the following properties:
 - density
 - light output
 - energy resolution
 - excitation spectra
 - emission spectra
 - radioluminescence
 - decay time

The results of these experiments are discussed below in paragraphs 8-14.

- 5. The sample LYSO crystals obtained from Saint-Gobain were processed in the same manner as the LSO crystals Siemens uses in its own PET scanners. The two LYSO crystals were 1x1x0.5 cm, with no surface finishing (as cut).
- 6. The tests performed by Siemens to measure these properties of the sample LYSO crystals were the same as those typically performed by Siemens on the LSO crystals Siemens uses in its own PET scanners. Thus, data for each of the characteristics listed above has also

been provided for Siemens' LSO crystals for purposes of determining whether the performance of LYSO crystals is substantially similar. In order to maintain a relative comparison standard, LSO pixels taken from Siemens' production were tested on the same apparatus as that used to test the LYSO. Siemens' also maintains a database of crystal slab measurements (including energy resolution and light output) as part of its quality control program. These slabs are then cut into pixels which are then classified based on their light output characteristics into 5 categories.

- 7. Siemens also sent portions of the sample crystals to an outside laboratory for destructive testing to determine the composition of the crystal. The report of that laboratory is attached as Exhibit C. The report indicates that the amount of yttrium in the LYSO crystals tested is approximately 4% by weight.
- 8. To measure the density of the sample LYSO crystals, each crystal was weighed three times. Using the buoyancy technique, samples of the LYSO were measured in air (dry mass) and in water (wet mass) at a known temperature in order to calculate their density. The relationship between dry mass and wet mass is based on the Archimedes' principle. In this case the formula is (dry mass * density of water at specific temperature) / (dry mass wet mass). Taking an average of the three measurements for each crystal, the two sample LYSO crystals had densities of 7.13 and 7.09 g/cc. The raw weight measurements for the sample LYSO crystals are provided in the table attached as Exhibit D. In comparison, the average density of one of Siemens' LSO crystals is
- 9. To measure light output the samples were excited by a standard cesium-137 gamma ray source. The scale used for the light output measurements is expressed in arbitrary units, with

the light output of bismuth germinate ("BGO") being assigned a light output value of 100. Two of Saint-Gobain's crystals and four of Siemens' crystals were tested in this manner. These tests on the two Saint-Gobain crystals showed light outputs of 573 and 564. For comparison, the tests on the four Siemens' crystals showed light outputs of and and The raw measurements for these tests are provided in the table attached as Exhibit E.

10. From the light output tests, the energy resolution was calculated as the full width at half maximum of the 662 KeV gamma ray peak. Two of Saint-Gobain's crystals and four of Siemens' crystals were tested in this manner. The energy resolution for the tests on the two Saint-Gobain crystals showed energy resolutions of 8.1 and 9.4 percent. For comparison, the energy resolution for the tests on the four Siemens' crystals showed energy resolutions of and the energy resolutions of the tests are provided in the table attached as Exhibit E.

- 11. The excitation spectra of the sample crystals was characterized for ~420 nm emissions. The crystals were exposed to 250-400 nm wavelengths. Two of Saint-Gobain's crystals and four of Siemens' crystals were tested in this manner. A graph showing the results for these tests is included in Exhibit F. The data was normalized to the highest intensity peak for each crystal spectra.
- 12. The emission spectra of the sample crystals upon excitation by ultraviolet light was characterized in two tests, one using 300 nm excitation and another using 350 nm excitation. Two of Saint-Gobain's crystals and four of Siemens' crystals were tested in this manner. Graphs showing the results for these tests are included in Exhibit G. Again, the data was normalized to the highest intensity peak.

- 13. Radioluminescene measurements for the sample crystals were taken using a 35-kV, 100-μA, x-ray generator, and the emission intensity was measured along with the emission wavelength. Two of Saint-Gobain's crystals and two of Siemens' crystals were tested in this manner. A graph showing the results for these tests is included in Exhibit H. The data was normalized to 1 for intensity.
- 14. To measure the scintillation decay time for the crystals, crystal samples were excited with standard cesium-137 and the intensity of emissions was measured versus time. A time-correlated, single photon technique was used. Scintillation decay is exponential, and scintillation decay time is defined as the time required for scintillation emissions to decrease to 1/e of the maximum emission intensity. The following equation was fit to the data points to determine the scintillation decay time, t_1 :

$$y = A1*exp(-x/t_1) + y0$$

Two of Saint-Gobain's crystals and two of Siemens' crystals were tested in this manner. The resulting graphs and calculations for these four tests are included in Exhibit I. For Saint-Gobain's two sample LYSO crystals, the calculated decay times were 39.2 and 39.9 nanoseconds. For Siemens' two LSO sample crystals, the calculated decay times were and nanoseconds.

15. Based on my knowledge of the industry, I am unaware of any scintillation crystal manufacturer other than Saint-Gobain that is offering LYSO crystals in commercial quantities and grades. The basis of this knowledge comes from industry contacts, review of scientific literature, trade journals, and conferences and meetings.

I hereby declare, under penalty of perjury, that the foregoing statements are true and correct to the best of my personal knowledge.

Date: June 25, 2007

Viraj Doshi, Ph.D.

State of Tennessee: SS

Subscribed and sworn before me, in my presence, this 35 day of 50ne, 2007.

Notary Public, Knox County, TN

My commission expires 02-03-2010.

CERTIFICATE OF SERVICE

I, the undersigned, hereby certify that on July 9, 2007, I electronically filed the foregoing with the Clerk of the Court using CM/ECF, which will send notification of such filing(s) to the following:

> Jesse A. Finkelstein, Esquire Jeffrey L. Moyer, Esquire Kelly E. Farnan, Esquire Richards, Layton & Finger, P.A.

I also certify that copies were caused to be served on July 9, 2007 upon the following in the manner indicated:

BY EMAIL & HAND

Jesse A. Finkelstein, Esquire Jeffrey L. Moyer, Esquire Kelly E. Farnan, Esquire Richards, Layton & Finger, P.A. One Rodney Square Wilmington, DE 19801

BY EMAIL

Frederick L. Whitmer, Esquire Thelen Reid Brown Raysman & Steiner LLP 875 Third Avenue New York, NY 10022

> /s/Jack B. Blumenfeld Jack B. Blumenfeld (#1014)

CERTIFICATE OF SERVICE

I, the undersigned, hereby certify that on July 16, 2007, I electronically filed the foregoing with the Clerk of the Court using CM/ECF, which will send notification of such filing(s) to the following:

Jesse A. Finkelstein, Esquire Jeffrey L. Moyer, Esquire Kelly E. Farnan, Esquire Richards, Layton & Finger, P.A.

I also certify that copies were caused to be served on July 16, 2007 upon the following in the manner indicated:

BY ELECTRONIC MAIL and HAND DELIVERY

Jesse A. Finkelstein, Esquire Jeffrey L. Moyer, Esquire Kelly E. Farnan, Esquire Richards, Layton & Finger, P.A. One Rodney Square Wilmington, DE 19801

BY ELECTRONIC MAIL

Frederick L. Whitmer, Esquire Thelen Reid Brown Raysman & Steiner LLP 875 Third Avenue New York, NY 10022

/s/ Maryellen Noreika (#3208)

Maryellen Noreika (#3208)

EXHIBIT A

SAINT-COSAIN:07-cv-00190-SLR Document 24-4 nvo Filed 07/16/200724/Page 24 78771 VILLE SOUTH TON

RYSTALS & DETECTORS

801 COCHRAN ROAD, SOLOR, OH 48179 ELEPHONE (440) 249-7400 FAX (440) 349-6581 MACID: A REMIT I FLATTIC. Dr. P.O. HOX 641218 Pittsburgh, PA 15261-7228

Ship Via UPS F.O.B.

NEWBURY, OHIO

Ship Term PREPAID

Bill To:

2637 UNIVERSITY OF TENNESSEE NUCLEAR ENGINEERING 1004 ESTABROOK

Ship To:

UNIVERSITY OF TENNESSEE ATTN: WILLIAM F. HOLIWAY

308 DAUGHERTY HALL

KNOXVILLE

TN 37996

KNOXVILLE

TN 37996

Payment VISA	Terms	Sales Rep # 200	Cust PO VISA	
FAX: 865 PHONE: 8	Qty Part No. 974-0880	WILLIAM HOLIWAY	Unit Price	Value !
GM-03-35 VISA 47 10	715 7804 00 2 100-17		x 10mm 1000.000	2000.00

APPROVED 010843

ALL FUNDS PAYABLE IN US \$ UPS # 1Z 490 752 034 435 69 19

		Sale Amount	2000.00	
		Misc Amount	.00	
	FOR EXPORT ONLY	Sales Tax	.00	
THESE COMMOCITIES LICENSED BY THE UNITED STATES FOR ULTIMATE DESTINATION	TO THE STREET BOOK OF THE STREET STREET	Freight	.00	
AND FOR DISTRIBUTION OR RESALE IN	United States by prohibits disposition of these consedities to communications trained around the viernes are democial.	TOTAL	2000.00	
IND FOR DISTRIBUTION OR RESALE IN Company of Valence and Grand Country Herbs Resear, unless that anytherized by the United States, INVERSION CONTRACT TO D. S. LAY PRO- INSTITUTE USA unless otherwise designates.		UNLESS OTHERWISE NOTED, INTEREST OF 1 1/22 PER PORTH OR 18% PER ARMSH FILL BE CHARGED ON ANY INPAIS BALANCE FAST SUE. In a septe experted by this deciment uses manyfastured in compliance will the Fair Later Standards Act of 1998, as garners.		

Case 1:07-cv-00190-SLR
SAINT-GOBAIN
CRYSTALS & DÉTECTORS

Saint-Sebain Caramics & Plantics, Inc.

Document 24-4 Filed 07/16/2007 Page 3 of 24 Sales Order

Sales Order Packing List Order

3/23/04 1/07/04 78771

1/0//04

Ship Via UPS
F.O.B. NEWBURY, OHIO
Ship Term PREPAID

12345 KINSMAN RD, NEWBURY, OH 44065 TEL 440-564-2251 FAX 440-564-8047

TEL 440-564-2251 FAX 440-564-8047

Ship To:

UNIVERSITY OF TENNESSEE ATTN: WILLIAM F.HOLIWAY 308 DAUGHERTY HALL

KNOXVILLE

TN 37996

Payment Terms VISA Sales Rep # 4200

Cust PO

VISA

Order Backord Shipped
Line Qty. Qty. U/M Part Number Description Qty
FAX: 865-974-0880 WILLIAM HOLIWAY

FAX: 865-974-0880 PHONE: 865-974-5264

GM-03-3584

10 2.0

.0 EA 100-1769

LYSO 5mm X 10mm X 10mm

2.0

Crystals

Charge to R011316041 - 4001550

No of Cartons / Weight 3# Carrier 2054293 Date Shipped 3/35/

PACKING LIST

PERSON

EXHIBIT B



FAX NO .:

PHONE:

+1 (865) 9744115

+1 (865) 974-5340

Univ of Tennessee Atta: William F. Holiway
308 Dougherty Hall Customer REF#
Knoxville, TN DATE-

GM-03-3584

CUSTOMER REF #:

December 08, 2003

37996

PAYMENT TERMS:

Net 30

SHIPPING TERMS:

* UTK Destination

Please refer to top quote # when placing order.

* Thanks for taking care of shipping.

ITEM	QTY	DESCRIPTION	UNIT PRICE US \$	TOTAL PRICE US \$
1 ((2)	LYSO 5mmx10mmx10mm Not Polished CC 3[25]04	\$ 1,000.00	\$ 2,000.00
		Shipment after receipt of order in 8-10 Weeks Minimum Order Amount \$500.00 NOTE: Lead times are based on our current workloads. A firm delivery date will provided at the time of order.	TOTAL	\$ 2,000.00

NOTE: The prices quoted herein are valid for: 60 days

Product contains 100% new material.

Country of Origin:

France

Scintillation Materials:

France

Assembly & Test:

Margaret DeLuca Customer Service Representative Saint-Gobain Crystals & Detectors

cc: David Stadelman Dominique Rothan Sandra Clarke

12345 Kinsman Road

Saint-Gobaln Crystals & Detectors Newbury, Ohio 44085 Tel: (440) 564-2251 Saint-Gobein Ceramics & Plastics, Inc.

Fax: (440) 564-8047

EXHIBIT C



TEST REPORT

NORTHERN ANALYTICAL LABORATORY, INC.

23 Depot St., Merrimack, NH 03054

Phone: (603) 429-9500 FAX: (603) 429-9471

> Dr. Piotr Szupryczynski Siemens Medical Solutions, USA Molecular Imaging 203 Dunavant Dr. Rockford, TN 37853

RECEIVED

IDENT AS MATERIAL

CONDITION TEST TO

TEST PER

2/26/07

See below (LuY)2SiO5

Solid

TP-ICP1

SAMPLE NUMBER

REPORT DATE **PAGE**

GI35782

2/27/07 1 of 1

CLIENT ORDER

Method:

ICP-MS analysis

Sample I.D.

24 LYS 013-1 S#2

<u>Y(wt%)</u>

 4.14 ± 0.1

Analysis By:

Peter S. Dickson

Analytical Chemist

Approved By:

William A. Guidoboni

Sr. Analytical Chemist





This test report shall not be reproduced, except in full, without the written consent of Northern Analytical Laboratory. The recording of false, fictitious, or fraudulent statements/entries on the certificate may be punished as a felony under federal law.



Glow Discharge Mass Spectroscopy NORTHERN ANALYTICAL LABORATORY, INC.

23 Depot St., Merrimack, NH 03054

Phone: (603) 429-9500 FAX: (603) 429-9471

FILE NO. 4SIEM1 DATE: 2/27/2007

GI35782

www.northernanalytical.com Piotr Szupryczynski Ph.D.

Lu2SiO5

Siemens Medical Solutios

203 Dunavant Dr.

PO#

SAMPLE NO.

Rockford, TN 3785	53	# 24LYS013-2			
ANALYSIS	ppmw	ANALYSIS	ppmw	ANALYSIS	ppmw
H		Zn	<0.5	Pr	0.03
Li	<0.05	Ga	<0.5	Nd	0.07
Be	< 0.05	Ge	<0.5	Sm	0.09
В	0.09	As	<0.5	Eu	0.70
E		Se		Gd	0.30
N		Br		Tb	0.65
0	Major	Rb		Dy	0.20
F	<1	Sr		Но	0.52
Na	0.75	Υ	Major	Er	0.10
Mg	0.15	Zr	0.15	Tm	0.04
Al	1.9	Nb	<0.1	Yb	14
Si	Major	Мо	≤0.1	Lu	Major
Р	0.35	Ru		Hf	<0.1
S	2.5	Rh		Та	<5
CI	6.0	Pd		W	<0.5
K	0.40	Ag	<0.5	Re	
Са	6.0	Cd		Os	
Sc	<0.1	In		lr	<u>≤</u> 0.5
Ti	0.16	Sn	0.15	Pt	<0.5
V	0.01	Sb	<0.1	Au	<5
Cr	0.20	Те	<0.5	Hg	
Mn	0.020			TI	
Fe	1.1	Cs		Pb	0.04
Со	<0.05	Ва	<0.5	Bi	<u>≤</u> 0.1
Ni	0.065	La	0.10	Th	<0.01
Cu	<u>≤</u> 0.1	Ce	600	U	0.10

All other elements <0.1ppmw, each





ANALYSIS BY:

William A. Guidoboni/ Sr. Analytical Chemist

Name/Function

APPROVED BY:

Richard J. Guidoboni / President

Name/Function

This test report shall not be reproduced, except in full, without the written approval of Northern Analytical Laboratory. The recording of false, fictitious, or fraudulent statements/entries on the certificate may be punished as a felony under federal law.

EXHIBIT D

Measurements on Saint Gobain Crystals

Sample ID	Dry Mass [g]	Wet Mass [g]	Water Density at 22.3C	Crystal Density [g/cc]
Saint Gobain 013-1#1	3.7213	3.2007	0.997704942	7.13169305
Saint Gobain 013-1#2	3.7213	3.2004	0.997704942	7.12758572
Saint Gobain 013-1#3	3.7211	3.2004	0.997704942	7.129940197
			Average:	7.129739656
	0.7004	2.4000	0.997704942	7.090470806
Saint Gobain 013-2#1	3.7204	3.1969		
Saint Gobain 013-2#2	3.7203	3.1972	0.997704942	7.095701963
Saint Gobain 013-2#3	3.7201	3.1972	0.997704942	7.098034339
			Average:	7 094735703

EXHIBIT E

Relative Light Output Measurements Cs137 (662eV)

Sample ID	Light Output	FWHM	ER
•	(photopeak position) [ch MCA]	[ch MCA]	ΔΕ/E [%]
LYSO Saint Gobain 013-01	573	53.93	9.411867
LYSO Saint Gobain 013-02	564	45.87	8.132979
LSO Ref#1			
LSO Ref#2			
LSO Ref#3	-		6
LSO Ref#4			
BGO	100	11.92	11.92

EXHIBIT F





EXHIBIT G






EXHIBIT H




EXHIBIT I

